



## Image Vault® Installation Considerations

*The Image Vault® Digital Video Recorder is a PC based product That is sensitive to its installation environment. Please ensure the Following steps are taken to reduce the possibility of failures when Installing the Image Vault in a harsh environment.*

### **Image Vault, LLC reserves the right to void the manufacturer's warranty on products that show evidence of a harsh environment installation.**

**Any** of the points below can and will be considered a *harsh environment* when related to the installation of the Image Vault Digital Video Recorder:

- Installation in an area where the nominal temperature exceeds 95° F / 35° C.
- Installation in a lock box.
- Installation on any surface that has repetitive seismic activity.  
*Ex. Vibrations generated by any machines with direct or indirect contact with the mounting surface of the DVR*
- Installation in a moisture rich area, or area with a constant excessive level of relative humidity.
- Installation of the DVR without a Tripp-Lite™ UPS or approved surge protector.
- Installation of any other electrical device plugged into the provided Tripp-Lite™ UPS.
- Installation of the DVR within 6 feet of high power equipment *(In excess of 500 Volts)*
- Installation or physical connection to unknown/unapproved equipment.  
*(Contact Tech. Support or visit our web site for the latest list of approved devices/equipment)*

It is recommended that the DVR have semi-annual preventative maintenance, consisting of dust removal from power supply fan by means of compressed canned air. Removal of the case is not necessary to perform this preventative maintenance.